
Combined Service Manual

HP LaserJet 4 / 4M
(C2001A / C2021A)

HP LaserJet 4 Plus /
4M Plus
(C2037A / C2039A)

HP LaserJet 5 / 5M
/5N
(C3916A/C3917A/
C3952A)

© Copyright
Hewlett-Packard
Company 1996

All Rights Reserved.
Reproduction, adaptation,
or translation without
prior written permission
is prohibited, except as
allowed under the
copyright laws.

Publication number
C3916-90984

First edition, March 1996

Printed in USA

Warranty

The information
contained in this
document is subject to
change without notice.

Hewlett-Packard makes
no warranty of any kind
with regard to this
material, including, but
not limited to, the
implied warranties or
merchantability and
fitness for a particular
purpose.

Hewlett-Packard shall
not be liable for errors
contained herein or for
incidental or
consequential damaged
in connection with the
furnishing, performance,
or use of this material.

WARNING

Electrical Shock Hazard

To avoid electrical shock,
use only supplied power
cords and connect only to
properly grounded
(3-hole) wall outlets.

Conventions

This manual uses the following conventions:

Unless specifically stated otherwise, information applies to all seven printer models (LaserJet 4/4 Plus/4 M/4 M Plus/5/5 M/5 N). Most procedures are combined for all printers, except where they differ substantially.

Color is used to emphasize items which are important to the material under discussion.

The names of major printer parts and assemblies are Capitalized.

Bold is used for emphasis, particularly in situations where *italic* type would be confusing.

Italic type is used to indicate related documents or emphasis.

COMPUTER type indicates text as seen on a computer monitor.

DISPLAY type indicates text as seen on the printer's 16 character LCD display panel (LaserJet 4Plus/4MPlus only).

KEYFACE indicates keys on a computer keyboard or on the printer's control panel. Examples include **Enter**, **On Line** and **Go**.

Note Notes contain important information set off from the text.

CAUTION Caution messages alert you to the possibility of damage to equipment or loss of data.

WARNING! Warning messages alert you to the possibility of personal injury.

Contents

1 Product Information

Product Family Information	1-2
Identification	1-3
Specifications	1-5
HP LaserJet 4 and 4 Plus	1-5
Related Documentation	1-7
Safety Information	1-8
Product and Laser Safety	1-8
FCC RFI Statement	1-9
Laser Statement (Sweden/Finland)	1-10
Toner Safety	1-11
Ozone Statement	1-11
Doing Business with HP	1-12
Technical Assistance	1-12
HP ASAP 1-800-333-1917 (U.S.)	1-12
HP FIRST	1-12
HP FIRST, U.S.	1-12
HP FIRST, Europe	1-12
HP AUDIO-TIPS	1-13
HP CompuServe Forum	1-13
Customer Information Centers	1-13
Customer Support Center (Assist Line)	1-13
Printer Drivers	1-13
European Customer Support Center	1-14
Other Areas	1-14

2 Site Planning and Requirements

Site Requirements	2-1
Printer Space Requirements	2-2
Print Media Specifications	2-3
Adhesive Labels	2-5
Label Construction	2-5
Overhead Transparencies	2-6
Envelopes	2-6
Envelope Construction	2-7

3 Configuration

Introduction	3-1
Using The Control Panel	3-2

Control Panel Keys	3-2
Reset Menu	3-5
Control Panel Menus	3-6
Printer Features	3-13
Page Protection (HP LaserJet 4 only)	3-13
Resource Saving (HP LaserJet 4 Plus and 5 only)	3-14
I/O Buffering (HP LaserJet 4 Plus and 5 only)	3-15
EconoMode (HP LaserJet 4 Plus and 5 only)	3-16
Resolution Enhancement (REt)	3-16
Memory Enhancement technology (MEt)	
(HP LaserJet 4 Plus and 5 only)	3-17
Density	3-17
Network Security	3-18
Remote Control Panel (DOS)	3-18
HP LaserJet Utility (Macintosh)	3-18
HP JetAdmin Utility (Novell Networks)	3-19
Service Mode	3-20
Setting the Page Count	3-21
Setting the Cold Reset Default	3-22
Cold Reset	3-23
Understanding the PCL Self Test Printout	3-24
Changing the Control Panel Display Language	3-28
Test Print Button	3-29
System Configuration	3-31
MS-DOS System Configuration	3-31
Parallel DOS Commands	3-31
Serial MS-DOS Commands	3-32
Printer I/O Configuration	3-33
Parallel Menu	3-33
Advanced Functions	3-33
Serial Configuration	3-33
Serial Protocol	3-33
BAUD Rate	3-33
Pacing (Handshaking)	3-34
Serial Cable Pin-outs	3-35
DB-9 RS-232 Serial Connection — HP LaserJet 4	3-35
DB-25 RS-232 Serial Connection — HP LaserJet 4	
Plus/5	3-36
DB-25 Serial Connection — HP LaserJet 4	3-37
DB-25 RS-232 Serial Connection — HP LaserJet 4	
Plus/5	3-38
RS-422A Serial Connection (Not available on the	
HP LaserJet 4 Plus or 5 printers)	3-39
RS-422A Serial Configuration (LaserJet 4 only)	3-39
Modular I/O Configuration	3-40

Printer Drivers	3-41
Install Printer Drivers and Utilities	3-41
How to Obtain Printer Drivers	3-41
DOS Utilities	3-42
Packing the Printer	3-43
Repackaging Instructions	3-43
Packing Checklist	3-43
Installing The Optional Lower Cassette	3-44
Loading Paper into the Optional Lower Cassette	3-45
Envelope Feeder Installation	3-49
LaserJet 4 and 4 Plus	3-50
LaserJet 5	3-50
SIMM Installation	3-51
Protecting the SIMM Board	3-51
Memory Requirements	3-53
Accessing the SIMM Slots	3-55
Installing the SIMM Boards	3-55
Testing a SIMM Board	3-57
Memory SIMM	3-57
Running a Self Test Printout	3-57
Personality SIMM (PostScript)	3-58
Troubleshooting a SIMM Board	3-59
Service / Error Messages	3-59

4 Preventive Maintenance

Introduction	4-1
Life Expectancy of Consumables	4-2
Service Checkpoints	4-3
Cleaning Your Printer	4-4
Toner Cartridge	4-5
Saving Toner with EconoMode (HP LaserJet 4 Plus and 5 Only)	4-6
Storing the Toner Cartridge	4-6
Installing the Toner Cartridge	4-7
Non-HP Toner Cartridges	4-9
Clearing the TONER LOW Message	4-10
Periodic Maintenance Procedures	4-11
Removing the MP Tray (Tray 1) Pickup Roller and Separation Pad	4-11
Removing the PC (Tray 2) Pickup Roller	4-13
Removing the Lower Cassette (LC) or (Tray 3) Pickup Roller	4-14
Removing and Replacing the Transfer Roller	4-15

Removing the Transfer Roller	4-16
Replacing the Transfer Roller	4-16

5 Functional Overview

Introduction	5-1
DC Controller System	5-2
DC Controller Loads	5-3
Serial Data Communication	5-4
Solenoids	5-5
Photosensors	5-6
Microswitches	5-8
PC (Tray 2) and LC (Tray 3) Tray Size Sensing System	5-9
Motors	5-10
Paper Jam Detection	5-11
Formatter System	5-12
I/O Control	5-12
Memory Management	5-14
Data Processing	5-14
PjL Overview	5-15
Image Formation System	5-16
Photosensitive Drum	5-17
Drum Sensitivity	5-17
Cleaning Stage	5-18
Conditioning Stage	5-19
Writing Stage	5-20
Developing Stage	5-22
Transferring Stage	5-24
Fusing Stage	5-25
Paper Feed System	5-26
Printing from the MP Tray (Tray 1)	5-29
Printing from the PC Tray (Tray 2)	5-30
Power System	5-31
Basic Sequence of Operation	5-33
Standard Printer Operation	5-33
Timing Diagrams	5-34
Warmup Period	5-37
Standby Period	5-37
PowerSave	5-37
Initial Rotation Period	5-38
Print Period	5-40
Last Rotation Period	5-42

6 Removal and Replacement

Required Tools	6-2
Hardware Review	6-2
Removing the Covers	6-4
Right Side Cover Removal	6-4
Top Cover Removal	6-5
Left Side Cover Removal	6-7
Rear Door Removal	6-8
Font Door Cover Removal (LJ 5 Right Front Cover Removal)	6-10
Multi-Purpose (MP) Tray (Tray 1) Door Removal . . .	6-12
Multi-Purpose (MP) Tray (Tray 1) Removal	6-13
Assemblies Removal	6-15
Power Supply Removal	6-15
Paper Feed Assembly Removal	6-18
High Voltage Power Supply (HVPS) Removal	6-21
Fuser Assembly Removal	6-22
Control Panel and Overlay Removal	6-23
Removing the SIMMs Door	6-25
Formatter Cage Removal	6-27
Formatter PCA Removal	6-29
DC Controller Removal	6-33
DC Controller Installation	6-35
Main Motor Assembly Removal	6-37
Gear Assembly Removal	6-38
Fan Removal	6-39
Output Assembly Removal	6-41
Paper Exit Sensor (PS3) Removal	6-42
Scanner Assembly Removal	6-43
Lower Cassette Assemblies	6-44
Lower Cassette Sensor PCA Removal	6-44
Lower Cassette Pickup Motor Removal	6-45
Replacing Fuser Assembly Parts	6-47
Fuser Assembly Configuration	6-48
Removing the Fuser Roller Heat Lamp	6-49
Fuser Assembly Thermoswitch Removal	6-55
Thermistor Removal	6-56
Paper Control PCA Removal	6-59
Sensor PCA Removal	6-60
PS1 and PS2 Sensor Assembly Removal	6-61
High Voltage Contact Plate (HVCP) and Paper Guide Removal	6-62
Accessing the High Voltage Contact Plate and Feed Guide Assembly	6-62

Removing the High Voltage Contact Assembly and Feed Guide Assembly	6-67
Replacing the High Voltage Contact Assembly/Feed Guide Assembly	6-68
Interconnect PCA Removal	6-69

7 Troubleshooting

LaserJet 5 Error Map	7-A
Pre-Troubleshooting Procedures	7-1
Preliminary Operating Checks	7-1
Printer Message Troubleshooting	7-2
Printer Message Summary Table	7-2
Clearable Warnings	7-10
Printer Message Troubleshooting Procedures	7-12
Blank Display	7-12
MP/PC/LC (Tray 1/2/3) LOAD Message	7-13
Cassette Size Switches (SW603, SW604, SW605) Functional Check	7-15
Paper Size Sensing Lower Cassette	7-16
PC Empty Sensor (PS2) Functional Check	7-17
PS4 Check (MP Tray Empty Sensor)	7-17
12 Printer Open Message	7-18
SW601 Functional Check	7-19
13 PAPER JAM Message	7-20
PS1 (Input/Registration Sensor) Check	7-22
PS3 (Exit Sensor) Check	7-23
Pickup Motor Functional Test (M2)	7-23
Lower Cassette Functional Check	7-24
14 NO EP CART Message	7-25
16 Toner Low Message	7-25
41.X ERROR Message	7-27
50 SERVICE Error - Fuser Malfunction	7-29
51 ERROR Message	7-31
52 ERROR Scanner Malfunction	7-32
Laser/Scanner Assembly Functional Checks	7-32
57 (or 57.1) SERVICE Message (Main Motor Failure)	7-33
Main Motor Functional Checks	7-33
58 (or 57.2) SERVICE (Fan Failure)	7-34
Image Defect Summary	7-35
PS5 Check (MP Tray Paper End Sensor) Functional Test	7-44
Image Formation Troubleshooting	7-49
Half Self-Test Functional Check	7-49

Drum Rotation Functional Check	7-50
High Voltage Power Supply Assembly	7-51
Interface Troubleshooting	7-52
Communications Check	7-52
Test Message	7-52
AUTOEXEC.BAT Standard Configurations	7-53
Parallel DOS Commands	7-53
Serial MS-DOS Commands	7-53
Communications Checks	7-54
MIO Troubleshooting	7-56
Troubleshooting Hints	7-56
Explanation of Self Test Printout	7-57
Troubleshooting Aids	7-59
Component Locations	7-59
Repetitive Defect Template	7-67
Voltage Test Points	7-69
Measuring the DC Voltage Levels	7-69

8 Parts and Diagrams

How To Use the Parts Lists	8-1
Parts Lists and Illustrations	8-2
Accessory Parts	8-33
SIMM Memory	8-38
Miscellaneous Parts and Accessories	8-39
Parts List	8-40

A Duplexer

Functional Overview	A-2
Duplex Printing	A-3
Switchback Assembly	A-3
Holding Tray	A-3
Electrical Overview	A-5
Installing the Optional Duplexer	A-6
Removal and Replacement	A-8
Required Tools	A-8
Removing the Covers	A-9
Removing the Switchback Covers	A-9
Removing the Side Cover on Power Side	A-10
Removing the Side Cover on Gear Side	A-11
Removing the Back Cover	A-13
Removing the Front Cover	A-13
Removing Internal Duplexer Components	A-14
Removing the Fan/Motor/Solenoid/Sensor	A-14
Removing the Switchback Paper Guide	A-15

Removing the Paper Guide Assembly	A-16
Removing the Paper Roller	A-17
Removing the Control PCA	A-20
Removing the Power PCA	A-22
Removing the Holding Tray Center Paper Guide . . .	A-23
Removing the Holding Tray Belt	A-24
Removing the Holding Tray Paper Sensor	A-26
Removing the Switchback Assembly	A-27
Parts and Diagrams for the Duplexer	A-28

B LaserJet 5/5M/5N Printer

Product Information	B-2
Product Family Information	B-3
Identification	B-5
Specifications	B-6
HP LaserJet 5 / 5M / 5N	B-6
Related Documentation	B-8
Laser Statement (Sweden/Finland)	B-9
Control Panel Layout	B-10
Control Panel Keys	B-10
Control Panel Menus	B-13
To change a control panel setting:	B-13
Printing Menu	B-15
PCL Fonts Menu	B-17
PostScript Menu	B-18
Job Menu	B-18
Configuration Menu	B-19
Memory Configuration Menu	B-21
Parallel Menu	B-22
Serial Menu	B-22
Resets Menu	B-23
Test Menu	B-24
Service Mode	B-25
Setting the Page Count	B-26
Setting the Cold Reset Default	B-27
Skip Demo	B-28
Big Data	B-28
Diagnostics	B-28
Programming a Flash SIMM	B-29
Changing the Control Panel Display Language . . .	B-30
NVRAM Init	B-31
Understanding the PCL Self Test Printout	B-32
Infrared Communication	B-34
System Requirements	B-35

To Print Using the Infrared Port	B-36
Troubleshooting IR Printing Problems	B-38
Infrared Port Not Responding	B-41

